

FLEXI-SEAL PUD

FLEXIBLE WATERPROOFING MEMBRANE

Characteristics:

- Flexi-Seal PUD is a light blue, water-based polyurethane modified flexible waterproofing membrane.
- It is fast drying and UV stable, and can be recoated in as little as 4 hours in optimal conditions.
- Flexi-Seal does not require the use of any reinforcement, and is ideal for waterproofing of shower recesses, bathrooms, laundries, balconies and decks.
- It can be used in both internal and external waterproofing applications, over concrete, render, block work, fibre cement, gyprock, plywood and particle board surfaces.
- Easy to clean in water.
- Part of the Flexi-Seal waterproofing system, in conjunction with Universal Primer, Butylseal, and RLA ceramic tile adhesives.



Preparation:

- All areas to be waterproofed must be clean and dry, free of grease, oil and paint and all loose materials, as well as any other contaminants.
- Concrete should be allowed to cure for a minimum of 28 days prior to application of waterproofing.
- Sheet and timber substrates must be installed and fixed in accordance with the manufacturer's specifications.
- Prior to application, surfaces (in particular porous substrates) should be primed with *Universal Primer*.

Application:

- Flexi-Seal PUD is a Class III Membrane. Care must be taken in any immediate wet areas such as shower recesses.
- Wall-to-wall and wall-to-floor junctions require a bond breaker mechanism applied prior to the application of Flexi-Seal PUD. A neutral cure silicone is recommended. The bond breaker must be applied in accordance with AS/NZS 3740: 2004 Class III Wet Area Membranes.
- Should a tape be required on the junctions, use 80mm Butylseal Tape. Apply a wider 150mm Butylseal Tape over the trap area after it has been primed, and turn it down into the trap to help better secure the waste trap area.
- Apply the first coat of Flexi-Seal PUD to the overall pre-primed substrate areas, ensuring an even coverage using a brush, roller or airless spray.
- Allow to dry before applying a second, heavier coat at 90° to the first. Ensure complete coverage is achieved and no air bubbles exist.
- Apply a third coat if imperfections are present in the membrane.
- Ensure each coat has fully cured prior to application of additional coats.
- Average dry film thickness should be approximately 1mm, and should not be any less than 0.75mm.

Part of the

Flexi-SEAL
Licensed waterproofing system

Cleanup:

- Clean all equipment with water after use.

Packaging/Shelf Life:

- Flexi-Seal PUD can be stored for up to 12 months in an unopened container.
- Store in a dry area above ground, out of direct sunlight.
- Flexi-Seal PUD is available in 4L and 15L packaging.

Coverage:

- Flexi-Seal PUD will cover approximately 12m² per 15L pail in internal applications and 10m² per 15L pail in external applications.

Notes:

A Material Safety Data Sheet is available upon request.

Disclaimer: The information supplied is to the best of our knowledge true and accurate. The actual application of the product is beyond the manufacturers control. Any failure or damage caused by the incorrect usage of the product is not the responsibility of the manufacturer. The manufacturer insists that all workmanship must be carried out in accordance with AS 3958.1-2007. It is also the responsibility of the end user to ensure that the literature in their possession is the latest issue.



RLA Polymers NZ Ltd
24 - 28 Lady Ruby Drive
East Tamaki
Auckland 2013
New Zealand

SOLUTIONS FOR INDUSTRY

Phone: (09) 267 2772
Fax: (09) 268 0305
Email: sales@rlapolymers.co.nz
Web: www.rlapolymers.co.nz